



1. Verify the accuracy of the printout by matching a dimension in both length and width. The dimensions are marked in millimeter.

2. Cut along the dashed line to use as a template.

PLEASE NOTE:
The outline is the exact dimension of the brake system. We recommend adding 2mm to these dimensions for 100% clearance.

